

# Installation Manual

KIA PICANTO 5DR  
KIA-PICA-5-A



## COMPONENTS INCLUDED



x 2



x 2



CL-M02 x 2



CL-P01 x 4



CL-M03 x 2



CL-M01 x 2



CL-W01 x 1



# Installation

KIA PICANTO 5DR  
KIA-PICA-5-A

